

User Manual

DP-DL01D

EDX/DMX to DALI Interface



INDEX

1. INTRODUCTION	3
1.1 FEATURES	3
1.2 SPECIFICATIONS.....	3
1.3 FUNCTION.....	4
1.4 ABOUT EDX/DMX-512 WIRING.....	4
1.5 SYSTEM DIAGRAM.....	5
1.5.1 EDX TO DALI SYSTEM.....	5
1.5.2 DMX-512 to DALI System	7
2. OPERATION	8
2.1 ID SET.....	8
3 EDX TO DALI GUI.....	9
3.1 INSTALL EDX TO DALI	9
3.2 CONNECT TO EDX TO ETHERNET INTERFACE	9
3.2.1 Connect by Using USB Cable (Only Applicable to DP-107E).....	11
3.3 ID NUMBER OF DP-DL01D	12
3.4 SEARCH DALI DEVICES	12
3.4 CHANGE DALI ADDRESS	13
3.6 SET DALI DEVICE PARAMETERS.....	14
3.7 DALI SCENES.....	16
3.8 DALI COMMAND TEST	17
3.9 EDX TO DALI PATCH.....	18
3.10 DMX-512 TO DALI PATCH	20
LIMITED WARRANTY	21


1. Introduction

1.1 Features


1. Convert EDX signal to DALI signal
2. Convert DMX-512 to DALI
3. Control up to 64 DALI ballasts/drivers

1.2 Specifications

1. Power Input: AC 100 – 240V
2. Protocol: DALI, EDX, DMX-512
3. Dimension: 108(W)*90(H)*62(D)mm
4. Weight: 160g



1.3 Function



1. Power LED
2. System State LED
3. Firmware Programming Port
4. AC 100-240V Input
5. ID Number Switch
6. EDX/DMX-512 port
7. DALI port

1.4 About EDX/DMX-512 Wiring


The digital signal wiring is basically the same as RS-485 wiring. If you are not familiar with RS-485 wiring, please check EDX/DMX-512 wiring guide on Lite-Puter's website:

http://www.liteputer.com.tw/tech_guide.asp


1.5 System Diagram

1.5.1 EDX to DALI System


By Ethernet (DP-107E or DP-104)



By USB (Only Applicable For DP-107E)



1.5.2 DMX-512 to DALI System




2. Operation

2.1 ID Set

ID number can be configured by DIP switch.


The number configuration is based on BCD code.

Each switch on the 10 digit DIP switch represents as following figure.




Examples:


ID number is 01 (1)



ID number is 06 (2+4)



ID number is 11 (1 + 2 + 8)



3 EDX to DALI GUI

“EDX to DALI” is an application to configure DP-DL01D.

An EDX to Ethernet interface (PL-DP106E or DP-104E) is required to make “EDX to DALI” communicate with DP-DL01D.

Please refer the previous EDX to DALI wiring diagram.


3.1 Install EDX to DALI

Install “EDX to DALI” application in Windows




3.2 Connect to EDX to Ethernet Interface


Run the application and enter the IP address of the network interface. Then click “Connect”.




Or click “Search” to search the EDX to Ethernet interfaces on the network.



Click “Search” button to show all interfaces on the network.



Click "Select" button in the interface list to connect to the network interface.



3.2.1 Connect by Using USB Cable (Only Applicable to DP-107E)


It is also possible to use USB port of DP-107E to configure DP-DL01D.

Simply connect DP-107E's USB to the PC, and run EDX2DALI GUI. Click "Connect" in "Configure by USB to EDX Interface".



3.3 ID Number of DP-DL01D

Make sure that you select correct ID number of DP-DL01D in “EDX to DALI” GUI.




3.4 Search DALI Devices

1. Click “DALI Setting” tab



2. Click “Search”




If some DALI ballasts are previously addressed and some DALI ballasts are not addressed yet, please check “Expansion” and then click “Search”.

The newly installed ballasts will be addressed and the previous ballasts’ addresses will keep the same.

3. The searching progress window shows.

Please wait till all ballast are found.



4. When all ballasts are found. It shows the number that DALI ballasts are found.




DALI address are randomly addressed during search process.

You can use “Change DALI Address” function in “DALI Setting” tab to change the address after searching process.

3.4 Change DALI Address


In “DALI Setting” tab, find “Change DALI Address” part.

Select the DALI address and new DALI address and then click “Set” to change the address.



3.6 Set DALI Device Parameters

1. Click “DALI Params” tab



2. DALI parameters can be read/write.

Parameters

DALI Address	1	Read
Max Level	100	Set
Min Level	33	Set
Power On Level	0	Set
System Failure Level	80	Set
Fade Time (1-15)	4	Set
Actual Level	0%	

Reset Parameters

DALI Address	1	Reset
--------------	---	-------

Max Level: the maximum output level

Min Level: the minimum output level

Power On Level: the output level when power is supplied

System Failure Level: the output level when system fails

Actual Level: the real-time output level

Fade Time: the time to change from current output level to requested output level.

Please refer the table below for real fade time.


n	Fade Time
1	0,707 s
2	1.000 s
3	1,414 s
4	2.000 s
5	2,828 s
6	4.000 s
7	5,657 s
8	8.000 s
9	11,314 s
10	16.000 s
11	22,627 s
12	32.000 s
13	45,255 s
14	64.000 s
15	90.510 s

3.7 DALI Scenes

1. Click “DALI Scene Setting” tab



2. You can read/set DALI scenes by DALI address.



3. If you want to check the real-time output, please check “Real-Time Output”. The DALI output level will be controlled by the last changed slide bar.



3.8 DALI Command Test

1. Click "DALI Command" tab



2. You can set DALI dimming level or recall DALI scenes.

A screenshot of the DALI Command Test window. It contains two main sections: "Set DALI Level" and "Recall DALI Scene".
Set DALI Level: This section includes:

- A radio button group for "Broadcast" (selected) and "Address" (radio button is unselected).
- A dropdown menu showing the value "1".
- A horizontal slider with a blue arrowhead, currently at the 0% mark.
- Two buttons: "MAX" and "OFF".

Recall DALI Scene: This section includes:

- A radio button group for "Broadcast" (selected) and "Group" (radio button is unselected). A dropdown menu shows the value "0".
- A radio button group for "Broadcast" (selected) and "Address" (radio button is unselected). A dropdown menu shows the value "1".
- A "DALI Scene" section with a dropdown menu showing the value "0" and a "Recall" button.

3.9 EDX to DALI Patch


The “EDX to DALI Patch” function is to make EDX commands able to control DALI devices.

You can use EDX scene control panel (ECP-110T, ECP-310) to recall the scenes of DALI ballasts.


By doing this, a DALI system can be integrated to EDX system.

Please refer “EDX to DALI System Diagram”.

1. Click “EDX to DALI” tab



2. You can patch/map DALI address to EDX zone/channel. Click “Save” to store the change.



EX: DALI address 05 is patched to EDX zone1/channel 1:

EDX's zone1/ channel 1 command will control DALI address 05.

EDX's zone1 scene command will trigger the corresponding scene in DALI devices whose address is 05.



EX: DALI address 01 is patched to EDX zone 2/ channel 3

EDX's zone2/ channel3 command will control DALI address 01.

EDX's zone2 scene command will trigger the corresponding scene in DALI devices whose address is 01.




3.10 DMX-512 to DALI Patch

The “DMX-512 to DALI Patch” function is to make DMX-512 controller able to control DALI devices.

Please refer “DMX-512 to DALI System Diagram”.

1. Click “DMX-512 to DALI” tab



2. Set corresponding DMX-512 to DALI address mapping and click “Save” to store the change.

01=DMX 1	02=DMX 2	03=DMX 3	04=DMX 4	05=DMX 5	06=DMX 6	07=DMX 7	08=DMX 8
09=DMX 9	10=DMX 10	11=DMX 11	12=DMX 12	13=DMX 13	14=DMX 14	15=DMX 15	16=DMX 16
17=DMX 17	18=DMX 18	19=DMX 19	20=DMX 20	21=DMX 21	22=DMX 22	23=DMX 23	24=DMX 24
25=DMX 25	26=DMX 26	27=DMX 27	28=DMX 28	29=DMX 29	30=DMX 30	31=DMX 31	32=DMX 32
33=DMX 33	34=DMX 34	35=DMX 35	36=DMX 36	37=DMX 37	38=DMX 38	39=DMX 39	40=DMX 40
41=DMX 41	42=DMX 42	43=DMX 43	44=DMX 44	45=DMX 45	46=DMX 46	47=DMX 47	48=DMX 48
49=DMX 49	50=DMX 50	51=DMX 51	52=DMX 52	53=DMX 53	54=DMX 54	55=DMX 55	56=DMX 56
57=DMX 57	58=DMX 58	59=DMX 59	60=DMX 60	61=DMX 61	62=DMX 62	63=DMX 63	64=DMX 64

If DALI address 03 is patching to DMX-512 address 10, DMX-512's channel 10 signal will control DALI ballast whose address is 03.

Limited Warranty

1. Lite-Puter is only responsible for the product itself.
2. Lite-Puter warrants to repair any manufacturing defects within one year of distribution date.
3. Lite-Puter does not offer on-site service. Should a defect appear in Lite-Puter's product, please deliver the product to local distributors or Taiwan Headquarters.
4. This Limited Warranty does not cover:
 - a. Any fault caused by false usage or imprudence (collision, inadequate installation or adjustment, insufficient ventilation, or improper repairs)
 - b. Force majeure factors (flooding, earthquake, volcanic eruption, or other factors beyond Lite-Puter's control).
 - c. Labor costs incurred in diagnosis of defects; installation, reinstallation, wiring, rewiring, repairing, adjustment, or reprogramming of a product; or any other consequential expenses.
 - d. Other Lite-Puter or non-Lite-Puter products or devices offered, packaged, or sold with the product.
5. Lite-Puter does not warrant that the product will operate without interruption or free of error.

World Headquarters :

Lite-Puter Enterprise Co., Ltd.

Address: 11F, No. 189, Gangqian Rd., Neihu Dist., Taipei City 11494, Taiwan.

Tel: +886-2-27998099

Fax: +886-2-27993828

Website: www.liteputer.com.tw

E-mail: sales@liteputer.com.tw

Shanghai Factory :

Lite-Puter Technology (Shanghai) Co.,Ltd.

Address: No. 375, Xingmei Rd., Minhang Dist., Shanghai 200237, China

Zip Code: 201108

Tel: +86-21-54408210

Fax: +86-21-54403376

Website: www.liteputer.com.tw

E-mail: sales_china@liteputer.com.tw