A50 User Manual

Contents

- SA50 main unit x1
- Power supply x1
- RCA cable x2
- Antennas x2
- QSG x1

Interfaces and Functions



WiFi Antenna: Used for WiFi connection
WPS: Used to activate the device hotspot when necessary
Line input: Analog input used to connect audio devices via an RCA cable
Line output: Analog pre-audio output to other devices
Network connection: RJ45 used to connect to a wired Ethernet network
USB input: Used to connect local storage devices
Speaker terminals: Phoenix speaker terminal used to connect to speakers
Power input: DC power input used to connect the power adaptor
Bluetooth antenna: Used to pair with mobile devices using a popular wireless service



LED: Indicates the status of the device

Blinking White: Power on or Network Connecting Solid White: Network connected, WiFi and USB mode Solid Blue: Bluetooth mode; Solid Green: Line Input mode

IR: IR receiver window for remote control

Technical Specifications

	Wireless network	IEEE802.11 b/g/n 2.4G			
Connectivity	LAN	single 10/100M RJ45			
	Bluetooth	4.0			
Frequency Response		20Hz to 20kHz			
Power input		DC 32V, 5A			
Audio Source Input		USB 2.0, Analog RCA			
Audio Source Output		Analog RCA			
Speaker impedance		4-16 ohms			
Dimensions:		14.7x10.8x3.7CM			
Music format		MP3/AAC/AAC+/ALAC/APE/WAV			
Decoding		Up to 24bit/192kHz			

Remote Control





Installation Guide

- 1. Unpack: Verify all the accessories are included in the package.
- 2. Place: Put the amplifier at a safe and proper location.
- 3. Connect

Speaker Wire Connection

Properly wire the male phoenix connectors on the amplifier, noting positive and negative terminals match with the positive and negative terminals on your speaker.

Power connection

Power the amplifier with the power adaptor included in the accessories.

4. Download the App

Download the MUZO application from the App Store for iOS and Google Play for Android.





5. Configure

Option 1- Configuration via app

Step 1: Connect your mobile devices to your network.

Step 2: Open the MUZO application> press Add Device(+)

Step 3: Go for mobile device settings> Connect mobile device to hotspot SoundSystem_xxxx Step 4: After connected, back to the MUZO app > the app will jump to configuration step>choose the 2.4G network, enter password>wait for the device to be configured.

WI-I				
•	SoundSystem _1234		C MUZO Pla III 중 10:53 AM	
•	ChinaNet-kPu3			
•	KDS-TECH		WLAN	
-	NEOON		SoundSystem_1234 Unsecured Network	∻ (j)
	SELECT NETWORK		CONNECTING	
Ch	oose the network you want the device to e. only supports 2.4G networks.		() Keep your router, phone, and device close to each of	other.
	WiFi-2.4G 🔒 🤶		-	
\Box	Password			
	Please enter router password			
			Connecting	
	Continue		The speaker is connecting to 2.4G WIFI network	
	CONNECTED		NAME DEVICE	>
	\sim		Custom	
	\checkmark	N	SoundSystem_1234	~
	Current Wi-Fi strength of device: 100%		Bedroom	
			Den	
			Dining Room	
	Next		Family Room	



Option 2- Configuration via Web console

-1. Power the device.

-2. Choose the hotspot(SoundSystem_xxxx) in the WiFi setting on your cell phone or computer and connect to it.

-3. Open the web browser and enter 10.10.10.254

-4. Go for WiFi>choose you 2.4G router>enter password> click connect> Device will be connected> the device will show on the app.

		10.10.10.254/index.htr ×	1	10.10.10.254/index.ht	× The Party Street	and the second se
ChinaNet-kPu3	Mer.	← → C ☆ © 10.10.10.254 index.html#wifip	age	€ → 0 0 0	10.10.10.254/index.html#	&ul-state = dialog
KDS-TECH	Ilter	G Google II		C Setting	G Geog	le III W
SoundSystem_1234		WLAN: network disconnected		WLAN: network dir	connected	
ChinaNet-95Gc	100			Select A Wireless I	Network 🗿	
PrintServer_Setup_2033F0	34	Select A Wireless Network 🚳		RDtest6		
AIN.CR1		AIN.CR2		S WiFi-24G		Please input wireless password
FACT ADDALA	9 _al	WiFi-2.4G		AIN.CR1		
		KDS-TECH		S KDS-TECH		cancel connect
		ChinaNet-kPu3		ChinaNet-k	PuJ	
		RDtest6		AIN.CR1		

Option 3-Connection via LAN

-Power the device

-Plug in the wired cable to the RJ45 Ethernet, the device will show on the app in about 10 seconds.

Option 4-Bluetooth pair

Open the app>choose the Bluetooth mode > open the Bluetooth on the mobile device >Pair to device Bluetooth "SoundSystem"> once connected, you will hear a sound prompt.



Device Settings:



App Photo Gallery:

Playback Your Device List will show all available zones. Press a zone to see the information on the current source. While on the view for the source, swipe right to reveal the available sources. From there, you can select what source you want to hear next, or swipe left to return to the currently playing source.



You also have the ability to combine zones so that each zone is playing the same source at the same time.

Just press your finger on the zone you want to play what another zone is playing until it indicates it is ready to merge. Then, drag it on top of the master zone and release. In roughly 30 seconds, the zones will combine.

To separate zones, repeat the process, but this time drag the zone you want to free below the dotted line.



Play mode switch

- Use the remote control to switch the modes: WiFi, Bluetooth and Aux input.
 Please note: before changing modes, have to get each mode ready.
- 2. Changing play mode on the app, choose different modes on the source playback, choose to play in LINE IN or Bluetooth mode. Please note, back to WiFi play mode, only need choose any online source or any music from "MY MUSIC".

Play Sources

On the application, you can play music from

1) online sources from Spotify, Tidal, TuneIn, Napster and so on(some need premium account);

2) local music(local storage from mobile device-cell phone and tablets, home NAS, USB flash drive or hard disk drive), it will show on "MY MUSIC";

3) music playing in Aux Input(from cell phone, PC, MP3 or CD Player...) and Bluetooth mode.

Firmware update

The application will notify you in your app when there is a new firmware version available. It's recommended to update firmware whenever available as this might not only correct bugs or improve security, but could also add new features or services.



NeteaseMusic				
A new F/W is available 3.1.2310				
Not now Upgrade				
⊅ ≫ ———				
How to switch betweer	n solo and multi mode?			

FAQ

Q: Do your devices support airplay and third-party DLNA apps?

A: Yes. They support airplay and third-party apps like BubbleUPNP...

Q: How many zones can you group in one system?

A: 12 rooms is the maximum, while 8 zones are recommended.

Q: What distance can your wireless audio system cover?

A: Once the system is connected to your WiFi router, you can stream your music anywhere there is a WiFi signal.

Q: Can it play high resolution music?

A: Yes. Our devices can play APE and FLAC within the normal bit rate range. They also support decoding 24bit/192kHz music files.

Q: How many languages do you support?

A: Our devices will auto-detect your mobile device language and change automatically. Currently, we support English, French, German, Spanish, Chinese, Portuguese, Korean and Japanese and more on the way.

Q: What online music services do you support?

A: Spotify, Tidal, iHeartRadio, TuneIn, Napster, and more, with more pending.

Q: Can I play local music?

A: Yes. You can play music from "MY MUSIC" on the application from local storage devices such as mobile device storage, USB thumb drives, portable hard disk and NAS.

Q: Can the device work with Windows devices?

A: The Windows application is not available at the moment, but on the Windows PC, users can use iTunes, Foobar2000 and Spotify connect as a line input.

Website: <u>www.arylic.com</u> Facebook: arylic Support: support@arylic.com



@Copyright 2018 by Arylic. All Rights Reserved.

The information contained in this guide is believed to be accurate and reliable. Arylic assumes no responsibility for any errors contained in this guide. Arylic reserves the rights to make changes in the specifications and/or design of the above mentioned product without prior notice. The diagrams contained in this guide may also not fully represent the product that you are using and they are for illustration purposed. Arylic assumes no responsibility for any differences between the product mentioned in this guide and the product you may have.