



EOGO Sound (Shenzhen) Co.,LTD

Room 818, A Block, Galaxy Century Building, No 3069, Caitian Road, Futian, District, Shenzhen, China

Tel: 0755-8339 2233 Email: info@eogosound.com

Installation Process

Prepare for Installation Tools:

1. Level Ruler
2. Small Chainsaw
3. Batten
4. Electric Screwdriver
5. Screw
6. Wire Stripper
7. Multimeter
8. Power
9. Blade
10. PVA wood glue
11. Sticky Mesh
12. Seam Tape
13. Scraper
14. Utility Knife

Step 1: Draw the Outline

Trace the enclosure to draw the outline on the wall.



EOGO SOUND (Shenzhen) CO., LTD

Invisible Audio 14 years | www.eogosound.com

Room 2809, A Block, Galaxy Century Building, No.3069, Caitian Road, Futian District, Shenzhen, Guangdong, China 518000

Step 2: Make a hole

Follow the outline to make a hole on the wall by cutting tool.
We would recommend using a drywall saw or oscillating multi-tool.
You'll need a depth of around 55 millimeters for all EOGO speakers.



Step 3: Install the enclosure

- a) Place the batten into the hole and screw it in.
- b) Push the cable through the tiny round hole in the back of the enclosure and reserve a length of 20cm, use a spirit level when placing the enclosure, making sure to keep the enclosure level with the wall.
- c) Screw the enclosure to the wall.
- d) Test the cable for short circuits by using a multimeter.

EOGO SOUND (Shenzhen) CO., LTD

Invisible Audio 14 years | www.eogosound.com

Room 2809, A Block, Galaxy Century Building, No.3069, Caitian Road, Futian District, Shenzhen, Guangdong, China 518000



Step 4: Install the speaker

- a) Use a stripper to strip the cable back by around 10mm to avoid short circuits. Connect the cable to the terminals of the speaker. Make sure you connect the polarity correctly: the cable's positive side (words printed) to the positive terminal of the speaker (the red one), the cable's negative side (no words printed) to the negative terminal (the black one).
- b) Remove the double-side tape on the 4 sides of the enclosure.
- c) Place the speaker into the enclosure.
- d) Screw the speaker to the enclosure.
- e) Use a multimeter to test the other end of the cable to make sure the cable is connected properly.




EGO SOUND (Shenzhen) CO., LTD

Invisible Audio 14 years | www.eogosound.com

Room 2809, A Block, Galaxy Century Building, No.3069, Caitian Road, Futian District, Shenzhen, Guangdong, China 518000

Step 5 Brush the Powder

- a) Blend the Powder with water at a ratio of 1:1, add a little white PVA wood glue to strengthen the stickiness.
- b) Use Powder to brush and smooth the 4 sides of the speaker.
- c) Soak the seam tape for 15 minutes before sticking on the 4 sides of 4 sides of the speaker.
- d) Wait for the Powder dry completely, then move on to the next step: 24 hours would be recommended.
- e) Brush the Powder over the whole surface of the speaker.
- f) Use sticky mesh cloth to cover the speaker to avoid the wall cracking.
- g) Wait for 24 hours for the Powder to dry completely.
- h) Sand lightly and paint to match the original color of the wall.



Notice:

The total thickness of the attached materials on the surface of the speaker (Powder, Seam tape and Sticky mesh) should not exceed 2mm to prevent impacting the sound.

EGO SOUND (Shenzhen) CO., LTD

Invisible Audio 14 years | www.eogosound.com

Room 2809, A Block, Galaxy Century Building, No.3069, Caitian Road, Futian District, Shenzhen, Guangdong, China 518000